


**SHERWIN
WILLIAMS.**

Pro Industrial™ Waterborne Acrylic Dryfall Flat

B42W02181 White, B42B00181 Black, B42T00081 Ultradeep

CHARACTERISTICS

Pro Industrial™ Waterborne Acrylic Dryfall Flat is designed for professional airless spray application to interior ceilings and wall areas that are not subject to wear. With proper height-clearance, overspray is dry before it settles on floors, machinery or equipment. The dry overspray can then be easily removed by sweeping or by vacuum.

The bright, full-hiding, white can help increase an area's lighting efficiency.

Features :

- Overspray cleans up easily
- Provides good adhesion to Vulcraft® decking*
- White - Light Reflectance 87%
- Flash Rust Resistant
- Suitable for use in USDA inspected facilities

For use on properly prepared: Structural Steel, Galvanized Metal, Drywall and Plaster, Concrete and Masonry, Wood and fully cured Spray Foam Insulation**.

Recommended for use in: Warehouses, Industrial, commercial, and institutional buildings, Textile mills, Manufacturing facilities, Gymnasiums, Parking garage ceilings not exposed to direct weathering.

Finish: 0-10 units @ 85°
Color: White
Recommended Spreading Rate per coat (White):
 Wet mils: 6.0-9.0
 Dry mils: 1.9-2.9
 Coverage: 176-270 sq. ft. per gallon
 Theoretical Coverage: 513 sq. ft. per gallon @ 1 mil dry
 Approximate spreading rates are calculated on volume solids and do not include any application loss.

Drying Schedule @ 7.0 mils wet, @ 50% RH:
 Drying and recoat times are temperature, humidity, and film thickness dependent. Dry fall characteristics will be affected at temperatures below 77°F(25°C) or above 50% RH.

White & Black:	@55°F	@77°F	@110°F
To touch	1 hour	20 min.	15 min.
To handle	1.5 hour	45 min.	30 min.
To recoat	2 hours	1 hour	1 hour
To cure	1 day	3 hours	2 hours
Dry Fall out	15 ft.	10 ft.	10 ft.
Ultradeep:	@55°F	@77°F	@110°F
To touch	45 min.	30 min.	20 min.
To handle	1 hour	45 min.	30 min.
To recoat	2 hours	1 hour	1 hour
To cure	2 days	4 hours	3 hours
Dry Fall out	10-20 ft.	10 ft.	10 ft.

Tinting with CCE only:

White: 0-2 ounces per gallon
Black: Do Not Tint
Ultradeep: up to 12 ounces per gallon
 Not controlled for tinting strength. Check color before using.

White B42W02181

V.O.C. (less exempt solvents):
 less than 50 grams per litre; 0.42 lbs. per gallon
 As per 40 CFR 59.406

Volume Solids: 32 ±2%
Weight Solids: 54 ±2%
Weight per Gallon: 12.19 lbs
Flash Point: N.A.
Vehicle Type: Acrylic
Shelf Life: 36 months, unopened

COMPLIANCE

As of 11/25/2025, Complies with :

OTC	Yes
OTC Phase II	Yes
S.C.A.Q.M.D.	Yes
CARB	Yes
CARB SCM 2007	Yes
CARB SCM 2020	Yes
Canada	Yes
LEED® v4 & v4.1 Emissions	Yes
LEED® v4 & v4.1 V.O.C.	Yes
EPD-NSF® Certified	Yes
MIR-Manufacturer Inventory	Yes
MPI®	#118, 133

APPLICATION

Temperature:
 minimum 50°F / 10°C
 maximum 110°F / 43°C
 air, surface and material
 At least 5°F above dew point

Relative humidity: 75% maximum
 The following is a guide. Changes in pressures and tip sizes may be needed for proper spray characteristics. Always purge spray equipment before use with listed reducer. Any reduction must be compatible with the existing environmental and application conditions.

Reducer: Water
Airless Spray:
 Pressure 2000 p.s.i.
 Hose ¼ inch I.D.
 Tip .013-.017 inch
 Filter 60 mesh

Conventional Spray:
 Gun Binks 95
 Fluid Nozzle 63 C
 Air Nozzle 63 FB
 Atomization Pressure 60 p.s.i.
 Fluid Pressure 50 p.s.i.

Reduction: Not Recommended

Brush: Not Recommended

Roller Cover: Not Recommended

If specific application equipment is listed above, equivalent equipment may be substituted.

Make sure product is completely agitated (mechanically or manually) before use.

Apply paint at the recommended film thickness and spreading rate as indicated. Application of coating above maximum or below minimum recommended spreading rate may adversely affect coating performance.

When using spray application, use a 50% overlap with each pass of the gun to avoid holidays, bare areas, and pinholes. If necessary, cross spray at a right angle.

Overspray landing on hot surfaces may adhere to these surfaces. Immediately remove overspray from hot surfaces before adhesion occurs. Note that surface temperatures can be higher than air temperature.

SPECIFICATIONS

Steel:

1 coat Pro Industrial Pro-Cryl Primer or Pro Industrial DTM Primer-Finish or Pro Industrial Kem Bond HS or Zinc Clad Primer
 1-2 coats Pro Industrial Waterborne Dryfall

Aluminum:

1-2 coats Pro Industrial Waterborne Dryfall

Aluminum (Water Based Primer):

1 coat Pro Industrial Pro-Cryl Primer
 1-2 coats Pro Industrial Waterborne Dryfall

Concrete Block (CMU):

1 coat Pro Industrial Heavy Duty Block Filler or Loxon Acrylic Block Surfer
 1-2 coats Pro Industrial Waterborne Dryfall

Concrete-Masonry-Plaster:

1 coat Loxon Concrete & Masonry Primer (if needed)
 or 1 coat Loxon Conditioner (if needed)
 1-2 coats Pro Industrial Waterborne Dryfall

Drywall:

1-2 coats Pro Industrial Waterborne Dryfall

Galvanizing:

1-2 coats Pro Industrial Waterborne Dryfall

Pre-Finished Siding Interior: (Baked-on finishes)

1 coat Pro Industrial Bond-Plex Waterbased Acrylic
 or 1 coat Pro Industrial DTM Bonding Primer
 1-2 coats Pro Industrial Waterborne Dryfall

Previously Painted:

1-2 coats Pro Industrial Waterborne Dryfall

Spray Foam Insulation**:

1-2 coats Pro Industrial Waterborne Dryfall

Wood, Interior:

1 coat Premium Wall & Wood Primer
 1-2 coats Pro Industrial Waterborne Dryfall

*B42W02181 White and B42B00181 only

**For fireproofing purposes, check with the fireproofing insulation supplier for compatibility recommendations.

Pro Industrial™

Waterborne Acrylic Dryfall Flat

SURFACE PREPARATION

WARNING! Removal of old paint by sanding, scraping or other means may generate dust or fumes that contain lead. Exposure to lead dust or fumes may cause brain damage or other adverse health effects, especially in children or pregnant women. Controlling exposure to lead or other hazardous substances requires the use of proper protective equipment, such as a properly fitted respirator (NIOSH approved) and proper containment and cleanup. For more information, call the National Lead Information Center at **1-800-424-LEAD** (in US) or contact your local health authority.

Do not use hydrocarbon solvents for cleaning. Remove all surface contamination by washing with an appropriate cleaner, rinse thoroughly and allow to dry. Existing peeled or checked paint should be scraped and sanded to a sound surface. Glossy surfaces should be sanded dull. Stains from water, smoke, ink, pencil, grease, etc. should be sealed with the appropriate primer-sealer. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Iron & Steel - Minimum surface preparation is Hand Tool Clean per SSPC-SP2. Remove all oil and grease from surface per SSPC-SP1. For better performance, use Commercial Blast Cleaning per SSPC-SP6. Prime any bare steel within 8 hours or before flash rusting occurs. Primer required.

Aluminum - Remove all oil, grease, dirt, oxide and other foreign material per SSPC-SP1.

Galvanizing - Allow to weather a minimum of six months prior to coating. Solvent Clean per SSPC-SP1. When weathering is not possible, or the surface has been treated with chromates or silicates, first Solvent Clean per SSPC-SP1 and apply a test patch. Allow paint to dry at least one week before testing adhesion. If adhesion is poor, brush blasting per SSPC-SP16 is necessary to remove these treatments. Rusty galvanizing requires a minimum of Hand Tool Cleaning per SSPC-SP2, prime the area the same day as cleaned.

Concrete Block - Surface should be thoroughly clean and dry. Air, material and surface temperatures must be at least 50°F (10°C) before filling. Use Pro industrial Heavy Duty Block Filler or Loxon Acrylic Block Surfacer. The filler must be thoroughly dry before topcoating.

Drywall - Must be clean and dry. All nail heads must be set and spackled. Joints must be taped and covered with joint compound. Spackled nail heads and tape joints must be sanded smooth, and all dust removed prior to the application of paint.

Wood - Surface must be clean, dry, and sound. Prime with recommended primer. Knots and pitch streaks must be scraped, sanded and spot primed before full coat of primer is applied. All nail holes or small openings must be properly caulked. Sand to remove any loose or deteriorated surface wood and to obtain a proper surface profile.

SURFACE PREPARATION

Masonry - All masonry must be free of dirt, oil, grease, loose paint, mortar, masonry dust, etc. Clean per SSPC-SP13/Nace 6/ ICRI No. 310.2R, CSP 1-3. Poured, troweled, or tilt-up concrete, plaster, mortar, etc. must be thoroughly cured at least 30 days at 75°F. Form release compounds and curing membranes must be removed by brush blasting. Brick must be allowed to weather for one year prior to surface preparation and painting. Prime the area the same day as cleaned. Weathered masonry and soft or porous cement board must be brush blasted or power tool cleaned to remove loosely adhering contamination and to get to a hard, firm surface. Apply one coat Loxon Conditioner, following label recommendations.

Previously Painted Surface - If in sound condition, clean the surface of all foreign material. Smooth, hard or glossy coatings and surfaces should be dulled by abrading the surface. Apply a test area, allowing paint to dry one week before testing adhesion. If adhesion is poor, additional abrasion of the surface and/or removal of the previous coating may be necessary. Retest surface for adhesion. If paint is peeling or badly weathered, clean surface to sound substrate and treat as a new surface as above. Recognize that any surface preparation short of total removal of the old coating may compromise the service length of the system.

Mildew - Clean mildew from the Surface: Mildew is a fungus that looks like dirt but won't wash off. Mildew must be removed before painting, or it will grow through any new coat of paint. To remove mildew or suspected mildew, scrub surface before painting with a commercial mildew remover following manufacturer's safety instructions.

PERFORMANCE

B42W02181 White

WVP Perms (US):

Method: ASTM D1653
grains/(hr ft² in Hg)

Results: 113.91 Perms

SAFETY PRECAUTIONS

Before using, carefully read CAUTIONS on label. Refer to the Safety Data Sheets (SDS) before use.

For use on interior surfaces.

During the early stages of drying, the coating is sensitive to rain, dew, high humidity and moisture condensation. Plan painting schedules to avoid these influences during the first 16-24 hours of drying.

FOR PROFESSIONAL USE ONLY.

Published technical data and instructions are subject to change without notice. Contact your Sherwin-Williams representative for additional technical data and instructions.

CLEANUP INFORMATION

Clean spills, spatters, hands and tools immediately after use with soap and warm water. After cleaning, flush spray equipment with compliant cleanup solvent to prevent rusting of the equipment. Follow manufacturer's safety recommendations when using solvents.

HOTW 11/25/2025 B42W02181 07 24
FRC,SP